

# OEM-1

## Application Guide 7-7-04

Cables to replace factory amplifier or adding an aftermarket amplifier				
("C" cable and AMP-RCA required with OEM-1)				"C" Cables
MAKE	MODEL	MODEL	YEAR	PART #
<b>CHRYSLER</b>	CHRYSLER INFINITY SYSTEMS		All-2001	ADD-CHR
<b>BUICK</b>	LE SABRE Bose not Concert Sound	PARK AVENUE Bose not Concert Sound	1995-2000	ADD-GM-32
	LE SABRE	PARKAVENUE	1988-94	ADD-GM21
	RIVIERA		1996-98	ADD-GM32
	RIVIERA		1990-95	ADD-GM21
	ROADMASTER		1995-96	ADD-GM21
	ROADMASTER		1991-94	ADD-GM21
<b>CADILLAC</b>	COUPE DEVILLE		1988-93	ADD-GM21
	COUPE DEVILLE		1985-87	ADD-GM12
	DEVILLE		1994-98	ADD-GM32
	ELDORADO		1992-99	ADD-GM32
	ELDORADO		1988-91	ADD-GM21
	ELDORADO		1983-87	ADD-GM12
	ESCALADE		1999-2002	ADD-GM21A
	FLEETWOOD		1988-93	ADD-GM21
	FLEETWOOD		1985-87	ADD-GM12
	SEVILLE		1992-97	ADD-GM32
	SEVILLE		1988-91	ADD-GM21
	SEVILLE		1984-87	ADD-GM12
<b>CHEVROLET</b>	CAMARO (Monsoon)		1998-2002	ADD-GM21C
	CAMARO		1990-97	ADD-GM21
	CAMARO		1986-89	ADD-GM12
	CAPRICE		1991-96	ADD-GM21
	CORVETTE		1997-2002	ADD-VET1
	CORVETTE		1990-96	ADD-GM21
	CORVETTE		1984-89	ADD-GM12
	LUMINA		1990-98	ADD-GM21
	SUBURBAN,TAHOE, BLAZER	2001-2002 TAHOE non Bose, use ADD-GM21C	1998-2002	ADD-GM21A
<b>GMC</b>	SUBURBAN , YUKON, JIMMY, ENVOY, DENAL		1998-2002	ADD-GM21A
<b>OLDSMOBILE</b>	AURORA		1995-2000	ADD-GM32
	BRAVADA		1998-2001	ADD-GM32A
	INTRIGUE		1998-2001	ADD-GM32
	NINETY EIGHT		1994-96	ADD-GM32
	NINETY EIGHT		1986-93	ADD-GM12
	TORONADO		1988-93	ADD-GM21
<b>PONTIAC</b>	BONNEVILLE		1999	ADD-GM21C
	BONNEVILLE		1992-98	ADD-GM21
	BONNEVILLE		1985-91	ADD-GM12
	FIREBIRD (Monsoon)		1998-2002	ADD-GM21C
	FIREBIRD		1990-97	ADD-GM21
	FIREBIRD		1986-89	ADD-GM12
	GRAND PRIX		2000-2003	ADD-GM21C
	GRAND PRIX		1998-1999	ADD-GM21B
<b>FORD / LM</b>	EXPLORER, CROWN VICTORIA, RANGER, MOUNTAINEER,CONTINENTAL		1998-2002	ADD-FRD3 (5)
	MUSTANG MACH SYSTEM	2000-2002 MUSTANG w/ 6 Disc Headunit - N/A (2)	1994-1999	ADD-FRD1
	ALL OTHER FORD - JBL & MACH SYSTEMS		1996-98	ADD-FRD2
	ALL FORD JBL SYSTEMS		1989-95	ADD-FRD1
	NAVIGATOR, EXPEDITION, EXCURSION	NAVIGATOR 2003	1999-2002	ADD-FRD3 (5)
	FORD LUX RADIO, STEREOs WITH NO ANTENNA PLUGGED INTO IT			N/A
<b>ACURA/ HONDA</b>	HONDA/ACURA/BOSE	1998 Acura w/bose	1986-97	ADD-HON
<b>NISSAN</b>	ALL NISSAN WITH BOSE SYSTEM		1989-94	ADD-NIS1
	ALL NISSAN WITH BOSE SYSTEM		1995-2002	ADD-NIS2
<b>MAZDA</b>	MAZDA BOSE SYSTEMS (except Millenia)		ALL	ADD-MAZ
<b>TOYOTA</b>	TOYOTA VEHICLES		1992-99	ADD-TOY
<b>VOLKSWAGEN</b>	VOLKSWAGEN BOSE		1987-99	ADD-VLK
Universal low level input harness for cars not listed above. (hard wiring required)				ADD-UNV
<b>AMP-RCA cable required when using "C" cables with OEM-1</b>				AMP-RCA
Notes:				
(1) OEM-1 is not required, this harness plugs directly into stereo "A" cable.				
(2) If adding a subwoofer amplifier only, use SNI-35. Connect to the factory subwoofer speaker wires. (5)				
(3) OEM-1 Not required. Requires SNI-35 if factory subwoofer is used.				
(4) Requires speaker level head unit				
(5) Requires model TR-4 to allow trigger on for aftermarket amplifiers to operate.				

## Cables to connect aftermarket stereos to factory amplifiers.

("A" and "B" cables required with OEM-1)

("A" and "B" cables required with OEM-1)				"B" Cables
MAKE	MODEL	MODEL	YEAR	Part #
<b>CHRYSLER</b>	CHRYSLER INFINITY SYSTEMS		ALL-2001	AMP-CHR
<b>BUICK</b>	LE SABRE Bose not Concert Sound	PARK AVENUE Bose not Concert Sound	1995-2000	AMP-GM32
	LE SABRE	PARK AVENUE	1988-94	AMP-GM21
	RIVIERA		1996-98	AMP-GM32
	RIVIERA		1990-95	AMP-GM21
	ROADMASTER		1995-96	AMP-GM21
	ROADMASTER		1991-94	AMP-GM21
<b>CADILLAC</b>	COUPE DEVILLE		1988-93	AMP-GM21
	COUPE DEVILLE		1985-87	AMP-GM12
	DEVILLE		1994-98	AMP-GM32
	ELDORADO		1992-99	AMP-GM32
	ELDORADO		1988-91	AMP-GM21
	ELDORADO		1983-87	AMP-GM12
	ESCALADE		1999-2002	AMP-GM21A
	FLEETWOOD		1988-93	AMP-GM21
	FLEETWOOD		1985-87	AMP-GM12
	SEVILLE		1992-97	AMP-GM32
	SEVILLE		1988-91	AMP-GM21
	SEVILLE		1984-87	AMP-GM12
<b>CHEVROLET</b>	CAMARO (Monsoon)		1998-2002	AMP-GM21D (1)
	CAMARO		1990-97	AMP-GM21
	CAMARO		1986-89	AMP-GM12
	CAPRICE		1991-96	AMP-GM21
	CORVETTE		1997-2002	AMP-VET1 (4)
	CORVETTE		1990-96	AMP-GM21
	CORVETTE		1984-89	AMP-GM12
	LUMINA		1990-98	AMP-GM21
	SUBURBAN,TAHOE, BLAZER	2001-2002 TAHOE non Bose use AMP-GM21D (1)	1998-2002	AMP-GM21A
<b>GMC</b>	SUBURBAN , YUKON, JIMMY, ENVOY, DENAL		1998-2002	AMP-GM21A
<b>OLDSMOBILE</b>	AURORA		1995-2000	AMP-GM32
	BRAVADA		1998-2001	AMP-GM32A
	INTRIGUE		1998-2001	AMP-GM32
	NINETY EIGHT		1994-96	AMP-GM32
	NINETY EIGHT		1986-93	AMP-GM12
	TORONADO		1988-93	AMP-GM21
<b>PONTIAC</b>	BONNEVILLE		1999	AMP-GM21C
	BONNEVILLE		1992-98	AMP-GM21
	BONNEVILLE		1985-91	AMP-GM12
	FIREBIRD (Monsoon)		1998-2002	AMP-GM21D (1)
	FIREBIRD		1990-97	AMP-GM21
	FIREBIRD		1986-89	AMP-GM12
	GRAND PRIX		2000-2003	AMP-GM21C
	GRAND PRIX		1998-1999	AMP-GM21B
<b>FORD / LM</b>	EXPLORER, CROWN VICTORIA, RANGER, MOUNTAINEER, CONTINENTAL		1998-2002	AMP-FRD3 (3, 4)
	MUSTANG MACH SYSTEM	2000-2002 MUSTANG w/ 6 Disc Headunit - N/A	1994-1999	AMP-FRD1
	ALL OTHER FORD - JBL & MACH SYSTEMS		1996-98	AMP-FRD2
	ALL FORD JBL SYSTEMS		1989-95	AMP-FRD1
	NAVIGATOR, EXPEDITION, EXCURSION	NAVIGATOR 2003	1999-2002	AMP-FRD3 (3, 4)
	FORD LUX RADIO-NO ANTENNA PLUGGED INTO HEAD UNIT			N/A
<b>ACURA/ HONDA</b>	HONDA/ACURA/BOSE	1998 Acura w/bose	1986-97	AMP-HON
<b>MAZDA</b>	MAZDA BOSE SYSTEMS (except Millenia)		ALL	AMP-MAZ
<b>NISSAN</b>	ALL NISSAN WITH BOSE SYSTEM		1989-94	AMP-NIS1
	ALL NISSAN WITH BOSE SYSTEM		1995-2002	AMP-NIS2
<b>TOYOTA</b>	TOYOTA VEHICLES EXCEPT LEXUS		1992-99	AMP-TOY
<b>VOLKSWAGEN</b>	VOLKSWAGEN BOSE		1987-99	AMP-VLK
<b>HUMMER by GM</b>	H1 (Monsoon)	Remote wire not needed	2000	AMP-VLK
Universal harness for cars not listed above. (hard wiring required)				AMP-UNV
Stereo cables to connect aftermarket stereos to OEM-1				"A" Cables
	ALPINE			ALP16
	AUDIOVOX			AUD14
	BLAUPUNKT			BLA16
	CLARION			CLA16
	CLARION 1999 & newer Models	1999 & 2000 Models		CLA16A
	ECLIPSE			ECL16
	ECLIPSE 1999 & newer Models	1999 & 2000 Models		ECL16A
	JVC			JVC16
	KENWOOD			KEN16
	PANASONIC			PAN16
	PIONEER	12 PIN PLUG		PIO12
	PIONEER	14 PIN PLUG		PIO14
	PIONEER	16 PIN PLUG		PIO 16
	ROCKFORD	2000 Models		ROC16
	SANYO			SAN12
	SONY			SON16
Universal harness for aftermarket stereos with speaker level outputs not listed above				RAD-UNV
Universal harness for aftermarket stereos with only pre-amp level outputs				RAD-RCA